


**HSP588**



atom

**WITH MOVABLE TROLLEY  
OILDYNAMIC CUTTING PRESS**

**Instructions, Use and  
Maintenance Manual**



## SUMMARY

<b>1</b>	<b>General information .....</b>	<b>7</b>
1.1	Important.....	7
1.2	Technical data .....	8
1.3	Acoustic emission of the machine.....	9
1.4	Programmed cut-counting device (optional).....	9
1.5	Overall dimensions.....	10
1.6	Optionals accessories .....	11
1.7	Recommended spare parts.....	11
1.8	Spare parts request .....	12
<b>2</b>	<b>Machine setting up .....</b>	<b>15</b>
2.1	Preliminary operations .....	15
2.2	Machine setting up.....	15
<b>3</b>	<b>Maintenance.....</b>	<b>19</b>
3.1	Maintenance operations .....	19
3.2	Troubleshooting .....	21
<b>4</b>	<b>Use and running.....</b>	<b>25</b>
4.1	Control devices.....	25
4.2	Control pannel.....	26
4.3	Stroke-end adjustment.....	27
4.4	Cutting operation .....	30
<b>5</b>	<b>Diagrams and nomenclature .....</b>	<b>35</b>
5.1	HSP 588 Wiring diagram nomenclature .....	35
5.2	Printed circuit card description.....	38
5.3	AL 81-82 Wiring diagram nomenclature.....	39
5.4	AL81-82 Wiring diagram .....	40
5.5	AL 85-86 Wiring diagram nomenclature.....	41
5.6	AL85-86 Wiring diagram .....	42
5.7	Oildynamic diagram.....	43
5.8	Oildynamic diagram nomenclature.....	44
<b>6</b>	<b>Spare parts.....</b>	<b>47</b>
6.1	Table 1 .....	47
6.2	Table 2 .....	48
6.3	Table 3 .....	49
6.4	Table 4 .....	50
6.5	Table 5 .....	51
6.6	Table 6 .....	52
6.7	Table 7 .....	53
6.8	Table 8 .....	54
6.9	Table 9 .....	55
6.10	Table 10 .....	56
6.11	Table 11 .....	57
6.12	Table 12 .....	58
6.13	Table 13 .....	59
6.14	Table 14 .....	60
6.15	Table 15 .....	61
6.16	Table 16 .....	62
6.17	Table 17 .....	63

6.18	Table 18 .....	64
6.19	Table 19 .....	65
6.20	Table 20 .....	66
6.21	Table 21 .....	67
6.22	Table 22 .....	68
6.23	Table 23 .....	69



## GENERAL INFORMATION





# 1 General information

## 1.1 Important

This travelling head press can be used to cut natural or synthetic leather/hide, cloth, cardboard, etc. No metallic materials or materials having metals inside, as well as materials which could be prejudicial to operator's health (i.e. asbestos) should be cut.

The machine must not be used in an explosive environment or to cut materials with hazard of explosion.

The machine must be used by a SINGLE operator.

The pictures in this instruction manual show the **HSP 588** travelling head press without accessories (see pertinent paragraph).

This machine is delivered with a kit of wrenches and a series of components of the rear table and its pertinent safety guards, to be assembled (for assembling see pertinent paragraph).

Any reproduction of this catalogue is absolutely prohibited.

ATOM S.p.a. expect you may utilize the product at the best with your full satisfaction.  
For any doubt or further advice, do not hesitate to contact ATOM S.p.a.



Atom SpA  
Via Morosini, 6 - 27029 Vigevano ( Italia )  
Tel. +39.0381.3021 - Fax +39.0381.344303  
www.atom.it - info@atom.it  
Service technical support:  
Atom SpA  
Via Morosini, 6 - 27029 Vigevano ( Italia )  
Tel. 800 – 256525

## 1.2 Technical data

Features		Machine types HSP 588			
		588/1	588/2	588/3	588/5
Maximum cutting power	ton	20	20	25	25
	kN	196	196	245	245
Cutting table: breadth extent	mm	1500	1600	1600	2000
	mm	430	500	500	500
Travelling head size: breadth extent	mm	430	500	500	500
	mm	430	500	500	500
Max daylight (without pad)	mm	175	175	175	175
Adjustable stroke	mm	5÷150	5÷150	5÷150	5÷150
Noise level	dba	See paragraph 1.3			
Travelling head speed: descent / cutting displacement	mm/s	105	105	85	85
	m/s	1.07	1.07	1.07	1.07
Max power motor pump	HP	2	2	2	2
	kW	1.5	1.5	1.5	1.5
Max power motor travel.head	HP	1	1	1	1
	kW	0.75	0.75	0.75	0.75
Weight (with oil)	Kg	1470	1495	1500	1800
Weight (with pallet)	Kg	1510	1535	1540	1850
Weight (with sea packing)	Kg	1750	1775	1780	2180
Dynamic overload	Kg	100	100	100	100
Hydraulic oil	Kg	50	50	50	50



### 1.3 Acoustic emission of the machine

Features of working and **NOT OPERATIVE** machine

**Leq** < 70 dB (A)

**Lpc** < 130 dB (C)

Features of working and **OPERATIVE** machine

- 1) Hide or synthetic leather, thickness 1.5÷2 mm at 15 SPM
  - with 1 layer **Leq** = 79 dB (A) and **Lpc** < 130 dB (C)
  - with 4 layers **Leq** = 84 dB (A) and **Lpc** < 130 dB (C)
- 2) Reclaimed leather, thickness 2 mm at 20 SPM
  - with 4 layers **Leq** = 75 dB (A) and **Lpc** < 130 dB (C)

NOTE:

The index level depends on the carrying out working (as well as on the machine setting up conditions); the index levels of any working are reported as an example.

CAPTION

**Leq**: equivalent continuous level of acoustic pressure at operator site

**Lpc**: level of sound pressure peak at operator site

### 1.4 Programmed cut-counting device (optional)

The travelling head press SP588 can be equipped, by request, with a programmed cut-counting device; in this case it is necessary point out as follows:

**IMPORTANT**: when it is reached the programmed number of cuts, the travelling head DO NOT EXECUTE its automatic return but it stops, when the cut has been performed, over the die. Disable the cut-counting device and use the proper pushbuttons to move the travelling head.

## 1.5 Overall dimensions




Fig. 1

Ref. (mm)	Machine types			
	HSP 588/1	HSP 588/2	HSP 588/3	HSP 588/5
A	2140	2140	2140	2540
B	2010	2010	2010	2160
C	1940	1940	1940	2340
D	200	200	200	200
E	1700	1700	1700	2100
F	1100	1100	1100	1500
G	965	965	965	965
H	25	25	25	25
I	1299	1379	1379	1379
L	700	700	700	700
M	9	9	9	9
N	430	500	500	500
O	150	150	150	150
P	143	143	143	143
Q	1520	1620	1620	2020
V	780	780	780	780
X	430x430	500x500	500x500	500x500

## 1.6 Optionals accessories

The machine can be equipped with the following optional accessories:

- material feeding devices: AL81 - AL82 - AL85 - AL86
- PR roll-holders (versions with 4-8-12 rolls)
- simple cut-counting device
- programmed cut-counting device
- magneto-thermal switch (pump and travelling head motors)
- shock absorbers
- set of wheels for machine displacement.

## 1.7 Recommended spare parts

On completion we also advise the following list of spare parts (**according to decreasing priority**):

- no. 2 cutting pushbuttons micro-interrupter s (code 02000310)
- no. 2 travelling head stroke-end micro-interrupter s (codes: 02000313+02000698)
- no. 2 travelling head displacement m micro-interrupters (code 02002346)
- no. 2 pushbuttons covers (code 02000051)
- no.1 set of printed circuit cards (codes: 02003100+03E02241)
- no.1 travelling head return potentiometer (code 02001422)
- no.1 insert for joint (code 01002010)
- no.1 electromagnet (code 02Z01746)
- no.1 outside horizontal flex. pipe (for HSP 588/1/2/3: code 02002300)  
(for HSP 588/5: code 02002357)
- no.1 flex. pipe tank-flow regulator connection (code 02003063)  
cod. 02003095; per HSP 588/2/3/5: cod. 02003062)
- no.1 flex. pipe flow regulator - delivery pipe connection  
(for HSP 588/1: code 02003095;  
for HSP 588/2/3/5: code 02003062)
- no.1 tank flex. pipe (code 02003110)
- no.1 set of piston seals (for HSP 588/1/2: codes: 02002294+02002293+02002292)  
(for HSP 588/3/5: codes 02001942+02001941+02001940)
- no.1 gear pump (for 50 Hz motor: code 02003066)  
(for 60 Hz motor: code 02003083)
- no.1 travelling head motor remote control reverse (code 02E03865)
- no.4 travelling head springs (for HSP 588/1/2: code 01010680)  
(for HSP 588/3/5: code 01010681)
- no.1 electro-valve (code 02003048)
- no.1 oil filter (code 01003863)

and the following **wear material**:

- no.1 cutting board (for HSP 588/1: code 02003098)  
(for HSP 588/2/3: code 02000738)  
(for HSP 588/5: code 02000739)
- no.1 striking plate (for HSP 588/1: code 01010679)  
(for HSP 588/2/3/5: code 01003584)
- no.12 screws (for HSP 588/1: code 02000585)  
(for HSP 588/2/3/5: code 02002145)
- no.12 washers (code 02000338)
- no.12 nuts (code 02000148)

## 1.8 Spare parts request

**IMPORTANT:** in order to guarantee the perfect efficiency of the machine it is imperative to use ATOM original spare parts.

For a quick supply of spare parts the following information is requested:

- a) required quantity
- b) part number (as shown in the spare parts catalogue pages)
- c) type of machine
- d) serial number of the machine

For instance:

no. 2 pieces, code 02000310, cutting press HSP 588 /...., Serial No.



## MACHINE SETTING UP





## 2 Machine setting up

### 2.1 Preliminary operations

Before connecting up the machine, ensure that the factory voltage corresponds to the one indicated on the label fixed on the left side of the machine (Fig. 1).

If, for any reason, the voltage of the motors should be changed (pump and trolley translation), it is imperative to adapt the transformer voltage to the desired one, moving the pertinent wire.

**Carry out this operation with the machine completely disconnected from the electric network !**




Fig. 1

### 2.2 Machine setting up

The machine is delivered already tested in our factory, with the right quantity of oil (50 Kg approx.) and the electric motors (pump and trolley translation) connected to the requested voltage.

On first switching on of the machine, through the main switch (A), the pump rotation direction is correct if:






Fig. 2

The travelling head moves correctly:

- to the left, when actuating the push-button for the trolley displacement (O)



- to the right, when actuating the push-button for the trolley displacement (I)



Should the trolley move to the opposite direction it is necessary to change the polarity of the connections.



## MAINTENANCE





## 3 Maintenance

### 3.1 Maintenance operations

For a good machine efficiency it is recommended to periodically carry out the following maintenance operations (points e) g) to be carried always when the machine is off !):

- a) clean the travelling head slides (code 01003574 - versions /1/2/3, code 01003575 - version /5, table. 3);
- b) check the correct chain pull monthly and, if necessary, provide for its adjustment by turning clockwise the turn buckle (code 01010596, table. 5) placed outwardly on the left side of the machine. Use a dynamometric wrench by applying a torque of  $1.5 \div 2.0\text{kgm}$ . approx. (Fig. 1)  
DO NOT EXCEED SUCH VALUES IN ORDER TO AVOID ANY DAMAGE TO THE GEARS !




Fig. 1

- c) turn upside-down the cutting board (code 02000737 - version /1, code 02000738 - versions /2/3, code 02000739 - version /5, table. 1) every week and level it whenever it presents wears or depressions of nearly 2 mm;
- d) turn upside-down and rotate of  $180^\circ$  the travelling head aluminum alloy plate (code 01010679 - version /1, code 01003584 - versions /2/3/5, table. 7) at least every three months to guarantee the flatness of the contact surface and its gradual wear;
- e) replace the hydraulic oil of the machine as well as of the relevant filter (code 01003863, table .9) every 8000 working hours;




Fig. 2

f) the hydraulic oil must have the following chemical-physical features (ISO 46, 3.5° - 4° Engler a 50° C):

- SHELL Tellus 46;
- ESSO Nuto H 46;
- TOTAL Azolla 46;
- AGIP Oso 46.

g) **IMPORTANT:** replacement of the micro-interrupter for control push-button (code 02000310) Respect the *safety* measure stated between the push-button upper side and the handle edge, as shown in the picture (table. 3).




Fig. 3

h) replace the oil of the travelling head translation device (code 03000761, table. 5) every 6000 working hours with one of equal to EP 460 (Kg. 0.400).




Fig. 4

### 3.2 Troubleshooting

- 1) TROUBLE: Actuating the control pushbuttons (I+L2 or O+L1) of the machine the travelling head does not to move:
  - a) check if the stroke-end adjusting handwheel (code 02001743, table. 6) has loosened: in such a case repeat the stroke-end adjustment; check, furthermore, the stroke-end micro-interrupter efficiency (code 02000313, table. 6);
  - b) check the micro-interrupter s of the travelling head displacement pushbuttons (code 02002346, table. 6);
  - c) check inside the electrical equipment, the travelling head motor remote control reverse (code 02E03865, table. 12);
  - d) check the 4A fuse of the 24V secondary (code 02001907, table. 12);
  - e) replace the printed circuit card (code 02003100, table. 12).
  
- 2) TROUBLE: Actuating simultaneously the cutting pushbuttons the machine does not cut:
  - a) check if the stroke-end adjusting handwheel (code 02001743, table. 6) has loosened: in such a case repeat the stroke-end adjustment;
  - b) check the micro-interrupter s of the cutting pushbuttons (code 02000310, table. 6);
  - c) check the 4A fuse (code 02001907, table. 12);
  - d) check the cutting electro-valve (code 02003048, table. 9);
  - f) check the correct functioning of the pump (for 50 Hz motor: code 02003066; for 60 Hz motor: code 02003083, table. 8).



## USE AND RUNNING







## 4 Use and running

### 4.1 Control devices

On the travelling head are located the mechanical controls for the cutting stroke-end adjustment and for the wished daylight between striking plate and cutting-die:




Fig. 1

(G) selector which allows either to insert the operating cycle (**AUTOMATIC**) or to adjust the cutting stroke-end (**ADJUSTMENT**);

(H) daylight adjusting hand-wheel: it locks the striking plate ascent in the wished position;

(I and L2) pushbutton for travelling head displacement from left to right;

(L1 and L2) synchronized cutting pushbuttons;

(M) screw for adjusting hand-wheel locking;

(N) cutting stroke-end positioning hand-wheel: it allows the striking plate stroke-end setting during cutting (cutting stroke-end). By turning it counter clockwise, the stroke-end sets up on the correct cutting height; by turning it clockwise the stroke-end value stores. **Do not turn the hand-wheel during cutting operation !**

(O and L1) pushbutton for travelling head displacement from right to left;

(P) micro adjustment ring nut: it advances (counter clockwise rotation) or delays (clockwise rotation) the cutting stroke-end, thus decreasing or increasing the cutting power;

(V) daylight adjusting lever: it locks the striking plate ascent in the wished position.

## 4.2 Control panel

The control panel, located on the left side of the machine, includes other electric controls:




Fig. 2

- (A) main switch
- (C) switch for feeding in and moving back the material (■)
- (D) potentiometer for travelling head return displacement
- (E) lamp switch
- (F) cut-counter switch (○)
- (Q) cut-counter device (optional)
- (T) potentiometer for striking plate ascent waiting time
- (U) selector for feeding rolls opening and closing (■)
- = only for machine equipped with feeder
- = only for machine equipped with cut-counter

### 4.3 Stroke-end adjustment

To adjust the cutting stroke-end of the machine, operate as follows:

- a) loosen the screw (M) and fully rotate anticlockwise the adjusting handwheel (H): the striking plate will rise up to its highest limit (Fig. 3).




Fig. 3

- b) move the selector (G) to **ADJUSTMENT** position and fully turn the handwheel (V) clockwise (Fig. 4).




Fig. 4

- c) place the cutting-die between the cutting board and the striking plate without any material to be cut (direct contact with the cutting board) (Fig. 5)




Fig. 5

- d) simultaneously press the synchronized pushbuttons (L): the striking plate will move downward till gently coming into contact with the cutting die (Fig. 6)




Fig. 6

- e) unloosen and immediately lock the cutting stroke-end positioning hand-wheel (N) (Fig. 7).




Fig. 7

- f) slowly turn counter clockwise the handwheel (V) till the daylight between striking plate and cutting-die is the wished one, keeping in mind also the thickness of the material to be cut; turn again clockwise the handwheel up to its highest limit (Fig. 8)






Fig. 8


- g) rotate clockwise the handwheel (H) to stop the stroke of the striking plate ascent in the wished position then block the screw (M) (Fig. 9);



- h) move the selector (G) to position **AUTOMATIC** and fully turn the handwheel counter clockwise up to its highest limit (1 turn approx.) (Fig. 10)



- i) press either the push-button (I and L2) to move the travelling head to left or the push-button (O and L1) to move the travelling head to right till unclamping the cutting-die (Fig. 11)



At this point the machine is perfectly adjusted to employ whatever cutting-die of the same height as the one used for the stroke-end adjustment.

**IMPORTANT:** If for any reason you should use cutting-dies with different heights, it will be necessary to repeat the previous procedure.

## 4.4 Cutting operation

Once the stroke-end adjustment procedure is executed (as described in the previous paragraph), the machine is ready to carry out a complete cutting cycle. Act as follows:

**IMPORTANT:** for a correct use of the cutting press we recommend to always place the cutting-die in the middle of the striking plate in order to avoid projections of the tool and, in the long run, substantial damages to the travelling head

- a)** lay the material to be cut on the cutting table and place the cutting-die in the working area;
- b)** actuate either the pushbutton for travelling head displacement from right to left (O and L1) or the pushbutton for travelling head displacement from left to right (I and L2) until the travelling head covers the cutting-knife completely (Fig. 12);




Fig. 12

- c)** simultaneously press the cutting pushbuttons (L) and keep them depressed until the striking plate carries out the complete cutting operation and starts its ascent; the travelling head will make the automatic return displacement towards the starting position: the amount of such an automatic return can be properly adjusted through the potentiometer (D) (Fig. 13);




Fig. 13

d) it is possible to adjust the cutting power through the ring nut (P) following indications written on the proper plate (Fig. 14);




Fig. 14

f) the potentiometer (T) is utilized to cut compressible materials (foam rubber, expanded materials, etc.) (Fig. 15);




Fig. 15





## DIAGRAMS AND NOMENCLATURE







## 5 Diagrams and nomenclature

### 5.1 HSP 588 Wiring diagram nomenclature


No.	Code	Components description
1	02000658	110V secondary circuit (2A) fuse
2	02E01551	30V secondary (6.3A) fuse
3	02001907	24V secondary (4A) fuse
4	02003100	Printed circuit card
5A	02E04530	24V AC/DC 1NO/NC relay-movement 1
5A		
5B	02E04530	24V AC/DC 1NO/NC relay-movement 2
5B		
6	02003102	Transformer (140VA)
7	02E05143	Inverter moving cart (VF-S15 4015 400V-1,5kW-TOSHIBA)
7	02E05495	Inverter moving cart (VF-S15 2015 220V-1,5kW-TOSHIBA)
8	02000280	Main switch
9	02001422	Striking plate ascent waiting time potentiometer
10	02001422	Travelling head return potentiometer
11	02001420	Lamp switch
12		
13		
14	02001420	AUTOMATIC / ADJUSTMENT selector
15	02000310	Cutting pushbuttons micro-interrupter s
16	02002346	Push-button for travelling head displacement from right to left
17	02002346	Push-button for travelling head displacement from left to right
18	02000313	Cutting stroke-end micro-interrupter
19	02003958	220/380V 50Hz pump motor
20	02004328	Three-phase motor 1HP 1400 RPM with splined shaft and servo fun
21	02003568	Travelling head motor fan (24V AC)
22	02002304	Lamp
23	02000313	Travelling head left stroke-end micro-interrupter
24	02000313	Travelling head right stroke end micro-interrupter
25	02004136	Cutting stroke-end positioning electro-valve coil
26	02004138	Cutting electro-valve coil
28	02001421	Cut-counting device switch (■)
29		Cut-counting device (■)
34	02E03889	380/415V travelling head motor thermal relay (■)
	02E03888	220/240V travelling head motor thermal relay (■)
35	02E03880	550V pump motor thermal rely (■)
	02E03911	380/415V pump motor thermal rely (■)
	02E03912	220/240V pump motor thermal rely (■)
60	02000658	Transformer 2A primary circuit fuse
61	02000658	Transformer 2A primary circuit fuse
J1	02E01734	10 pins card connector
J2	02009105	5 pins card connector
J3	02009105	4 pins card connector
J4	02009107	8 pins card connector

(■) = by request





## 5.2 Printed circuit card description



The **printed circuit card** (code 02003100, table. 13), which controls all the machine functions, is located inside the electrical equipment protecting cover (left side of the machine). To replace it, remove the cover through the fixing screws, operate on the card fixing screws and take out the card from its connectors: the whole operation must be carried out **only when the machine is off!**

As shown in the picture, there are 13 **signalling leds** on the printed circuit card which may be useful to trace possible anomalies in the main electric devices of the machine: the operator will be able therefore to verify these devices by checking the pertinent leds on the ground of the following list:


- DL1) **left pushbutton led:** its lighting up indicates the functioning of the left cutting pushbutton (N.15);
- DL2) **right pushbutton led:** its lighting up indicates the functioning of the right cutting pushbutton (N.15);
- DL3) **left travelling head displacement led:** this led lights up when pressing the pushbutton (N. 16) for the manual translation of the travelling head to left;
- DL4) **right travelling head displacement led:** this led lights up when pressing the pushbutton (N. 17) for the manual translation of the travelling head to right;
- DL5) **ADJUSTMENT-AUTOMATIC switch led:** this led lights up when the selector (N.14) is on AUTOMATIC position;
- DL6) **controls feeding led:** its lighting up indicates the feeding of the printed circuit card input circuits (it must light up on switching on the machine);
- DL7) **integrated circuits leds:** its lighting up indicates the feeding voltage in the integrated circuits of the printed circuit card (it must light up when switching on the machine);

- DL8) **right trolley displacement output led:** this led lights up when the printed circuit card feeds the remote control reverser coil (N.5) for trolley displacement to right;
- DL9) **left trolley displacement output led:** this led lights up when the printed circuit card feeds the remote control reverser coil (N.5) for trolley displacement to left;
- DL10) **cutting electro-valve output led:** its lighting up indicates the feeding of the electro-valve coil (N.26);
- DL11) **cutting stroke-end positioning electro-valve output led:** this led has to light up when the printed circuit card feeds the cutting stroke-end positioning electro-valve coil (N. 25) with the selector (N.14) on ADJUSTMENT position;
- DL12) **cutting stroke-end signal led:** this led has to light up when the striking plate reaches the stroke-end position;
- DL13) **ADJUSTMENT-AUTOMATIC switch led:** this led lights up when the selector (N.14) is on ADJUSTMENT position.

### 5.3 AL 81-82 Wiring diagram nomenclature

No.	Code	Part description
1	02002287	Remote control reverser for material feeding in/back motor
2	02002448	1/1.6A - 380/440V thermal relay for material feeding in/back motor (optional)
	02002449	1.6/2.5A - 220/240V thermal relay for material feeding in/back motor (optional)
3	02001346	220/380V 50Hz material feeding in/back motor
	02001347	260/450V 50Hz material feeding in/back motor
	02001348	240/420V 50Hz material feeding in/back motor
	02001349	220/380V 60Hz material feeding in/back motor
	02001350	250/440V 60Hz material feeding in/back motor
	02001351	320/550V 60Hz material feeding in/back motor
4	02001357	Foot treadle for material feeding in
5	02001385	Feeder plug
6	02002287	Remote control reverser for rolls opening/closing motor
7	02002448	1/1.6A - 380/440V thermal relay for rolls opening/closing motor (optional)
	02002449	1.6/2.5A - 220/240V thermal relay for rolls opening/closing motor (optional)
8	02001346	220/380V 50Hz rolls opening/closing motor
	02001347	260/450V 50Hz rolls opening/closing motor
	02001348	240/420V 50Hz rolls opening/closing motor
	02001349	220/380V 60Hz rolls opening/closing motor
	02001350	250/440V 60Hz rolls opening/closing motor
	02001351	320/550V 60Hz rolls opening/closing motor
9	01010162	Feeder tap
10	02001341	Rolls opening stroke-end micro-interrupter
11	02001341	Rolls closing stroke-end micro-interrupter
12	02001423	Rolls opening/closing swicth
13	02001423	Rolls opening/closing swicth

### 5.4 AL81-82 Wiring diagram






## 5.5 AL 85-86 Wiring diagram nomenclature


No.	Code	Part description
1	02002287	Feeder motor remote control reverser
2	02002448 02002449	1/1.6A 380/420V feeder motor thermal relay (optional) 1.6/2.5A 220/240V feeder motor thermal relay (optional)
3	02001346 02001347 02001348 02001349 02001350 02001351	220/380V 50Hz feeder motor 260/450V 50Hz feeder motor 240/420V 50Hz feeder motor 220/380V 60Hz feeder motor 250/440V 60Hz feeder motor 320/550V 60Hz feeder motor
4	02001357	Foot treadle for material feeding in



### 5.6 AL85-86 Wiring diagram



### 5.7 Oildynamic diagram



## 5.8 Oildynamic diagram nomenclature

No.	Code	Components description	Version
1	01003863	Suction filter	All
2	02003066 02003083	Oil-dynamic gear pump for 50Hz motor Oil-dynamic gear pump for 60Hz motor	All
3	02002831	High pressure relief valve	All
4	02003048	Cutting electro-valve	All
5	02003047	Stroke-end positioning electro-valve	All
6	02003049	One way restrictor for stroke-end adjustment	All
7	01010536 01010537 01010538	Cutting cylinder	588/1 588/2 588/3/5
8	01010545 01010546	Piston	588/1/2 588/3/5
9	01010617	Oil tank	All


## SPARE PARTS






# 6 Spare parts

## 6.1 Table 1




6.2 Table 2







6.3 Table 3




6.4 Table 4




6.5 Table 5




6.6 Table 6




6.7 Table 7




6.8 Table 8



6.9 Table 9




6.10 Table 10







### 6.11 Table 11




6.12 Table 12




6.13 Table 13




6.14 Table 14




6.15 Table 15




6.16 Table 16



6.17 Table 17




6.18 Table 18







6.19 Table 19




6.20 Table 20




6.21 Table 21



6.22 Table 22



6.23 Table 23



ATOM



atom

